

Y2E UNIVERSAL REMOTE CONTROL PROGRAMMING INSTRUCTIONS

Now you can be the master of your electronic devices with one simple to use remote control - the Y2E , just follow the easy programming instructions below and you will have the ultimate control of your home entertainment equipment right at your fingertips.

Step1. Install the batteries.

Step2. Program the Y2E. Press the “set” key, hold it and press device key, when the red light is on, release both keys, then input 3 digit brand code.

Step3. Test your remote control, Press the “power” key, the device will be turned on when the code is correct. If the device was not turned on, repeat step 2 until you find the right code.

If you can not find your entertainment equipment code on the Brand code list or after having tried all the brand codes on the list, and you still can not turn on your device. Please use the search mode to search. Procedures are as follows :

A. Turn on your device which you want to operate.

B. Press the ”set” key and device key until red light on.

C. Press the ”set” key again, remote control is in search mode.

D. Press the ”power” key every 2 seconds continually.

E. If you can turn on and off your entertainment equipment, then please press device key and red light off. Now your remote can control your entertainment equipment.

You can also use auto search mode, Procedures are as follows:

1. Press the “device” key you want to control.
2. Press the “set” key for 5 seconds until the red light on. Then release the “set” key at once, red light start blinking , now you are in the “auto search” mode.
3. When TV can be turned on or off, press “set” key within 1~2 seconds.
4. Now you can operate your TV.

Brand/Device	TV/TXT	VCR	SAT	CABLE	HIFI	CD	LD/VCD	AUX
AB			495					
ABC				452				
ACE	245							
Admiral	032,155							
Aiwa	261					581	653	
Akai	005,092,126,159	309,310,356,357						
		371,372						
Alba			407					
Albiral	001							
Alfa Gold			525,526					
Amstrad	006		408,488,524					
			535					
Anitsch		311						
Ankaro			536					
AOC	080							
Apollo			402					
ARC EN CIEL(F)	=> Thomson							
Aristona	=> Philips							
Arthur Martin	=> Salora							
ASA	007,009,013,032	383						
	094,155,161							
Asiagiant			409,488,535	501				
Asira								
Atlantic	=> White Westin Ghouse							
ATLE						579		
Audiosonic	160							
Aura			430,487					
Ausind	008							
	004,007,012,014							
Autovox	015,076,079,104							
	153							
AWA	033,159,160,189							
	220							
Baird	162	372,374						
Barcom			536					
Basic Line	163							
BEKO	226							
Benjamin			468					
BEST			453	498	568			
Blaupunkt	010,017,018,020	312,369,373,375						569(VHS)
	054,231,232,233	376						
	234,236,241							
Brandt	=> Thomson							
Electronique(F)								
Brionvega	104,155,164,165	377,384						
	200,201,257							
Bruns	158							
BSR	016,019,021							
Bush(UK)	022	382	402					
Cabletime	246,247,251			511,513	514			
Cambridge			538					
CANAL+			529					
Caravelli							622(VCD)	
Century	145,146,155							
	019,023,024,145	356,378						
	151,169,170,231							
CGE	093	291						
CGM	093							
Chaparral	216		410,537					
ChunYun						640		
Citizen/Candle	080,212							
Clarivox	001,166,167							
Concerto	080							
Condor	=> White Westin ghouse							
Contec	016							
Continental	Thomson							
Edison(F)								
Crosley	024,025,145,155							
	231							
CTC Clatronic	096							
Curtis Mathes	212							
CXC	278							
Daeewo	080,168,209							
Dansal		382						
DCS							667	
Decca(UK)	002,004,026,028	379						
	031,258							
Denon						645		564(TUNE) 566(DECK)
DNT			409,428,430					
			487					
Drake			445,446,447					
			539					
Dual	255,258	374,380						
Dual-Tec	004,011,019,029							
Dumont	155							
Dynasat			491,492					
Eastern				507,508	509,510			
Echostar			409,411,412					
			457,458,460					
			461,462,486					
			516,540,541					
			542,549					
Elbe	001,171	313						
ELCIT	=> Magnadyne							
Electrohome	092							
Elite	108							
Elman	019,029							
Emerson	059,080,146,155	387						
	278							
EMME ESSE			463,464,465					
Europhon	000,004,019,029							
	030,146							
Eurosky			421					
Eurostar			465					
Fenner	033,193,240							
Ferguson	=> Thorn Ferguson							

Brand/Device	TV/TXT	VCR	SAT	CABLE	HIFI	CD	LD/VCD	AUX
Fidelity(UK)	003,034,229							
Filmnet	202,248							
Finlux	007,008,009,013	379	414,415					
	025,026,029,035							
	094,161,169,221							
Fisher	025,036,155,167	314,315,316,381			627	644		
	170,205,255							
Formenti-Phoenix	003,008,025,037							
	038,159							
FORTEC STAR			533,534					
Fracarro			543,544					
France Telecom	264							
Freecom			426					
FTE			399					
Fuba			413					
Funai	016,059,160,278	359						
	002,004,019,025	382						
GBC	026,031,033,039							
	040,041,042							
GEC(UK)		379						
Geloso	004,019,025,032	382						
	033,039,149,150							
General		358						
Giucar Record			416,545					
GMI				499,515				
				519,521				
Golden				517				
Goldstar	003,004,026,043	383					658	
	080,153,172,252							
	267,268							
Goodmans	119	301						
Gorenje	170,173							
Graetz	=> ITT-NOKIA							
	002,004,027,041	314,369,373,379						
Granada(UK)	044,045,046,047	384						
	048,049							
Grundig	003,010,018,020	361,369,373,376	400,402,484					
	045,050,051,053	385	546					
	054,056,094							
Haitai							646	673
Hanseatic	025,027,037,044	379,386						
	052,055,258							
Hantarex	000							
Hemmermann	057							
HIFIVOX(F)	=> Thomson							
Hinari	033,044,058,059	317,360,382,387						
	060	388						
Hirschmann			415					
	004,040,041,042	374,382,386,389	483			628		
	044,047,055,061							
Hitachi	062,063,064,065							
	066,067,068,080							
	122,174,221,222							
Hotel TV								
Huth	253							
Hyper	003,004,033,153			421,479				
	193							
ICX International			417					
IEEC				506				
Imperial	019,023,024,145	289,378						
	151,169,170,231							
IMC Interactive TV				496				
IMS VOD				496				
Infinity	026							
Ingele	=> ITT-NOKIA							
Inkel							621	
Inno Hit	000,004,031,043							
	060,146,175							
Interfunk	005,027,040,045	290,379						
	046,052,069,070							
	071,073,075,155							
Irradio	008,039,043,060							
	153,262							
ITT-Nokia	005,032,040,041	290,291,292,316	418,532,547					
	045,049,069,070	356,374,377	548					
	071,072,074,076							
	162,168,176,177							
	249,250							
Janco								
JBL	026						623	624
Jaemon			549					
Jerrold				417,502				
Johansson			550					
JVC	077,119,178,179	292,318,319,320	605					
		321,328,356,374						
Kaisai	163							
KAPSCH	=> ITT-NOKIA							
Karcher	159,163,175						647	
Kathrein			419,469,551					
			552,553					
Kendo	146							
Kennedy	025,078,079						625,629	580
							630,631	648
Kenwood							632	572,655
Korting	037,155,157							
Krjesler	=> Philips							
KTY								
Legend-V	278							675
Lenco	033,039,183,238	325,355	423,426,480		595,596	060	585,586	
	239,240		481,482					

Brand/Device	TV/TXT	VCR	SAT	CABLE	HIFI	CD	LD/VCD	AUX
Luma	032,082	322						
Luxman	080							
Luxor	005,045,047,055 068,083,084,085 086,087,162,177	291,386	392,547,554			626		
LXI	225,275							
Macab		420						
Macom		444						
Magnadyne	000,019,025,029 057,147,149,150 155							
Magnafon	000,003,008,029 030							
Magnasonic	291							
Magnavox	026,080,477		477			576 604 651	571	
Marantz	026,027	301,373,379						
Maspro			393,402,490 551					
Matsui	004,006,028,041 088,182	322,332,388						
Maximal	058							
Meletronic	255							
Memorex		314,383						
Metz	018,053,089,090 091,155,180,183	294,369,370,373 376	546					
MINA		494						
Minerva	010,018,045,051 053	369,373,376	400,484,546					
Mission						651		
MGA/ Mitsubishi	044,052,080,082 119,154,155,181 182,286	293,320,362,379 382,391	489					
Mivar	000,003,093,094 095,259							
Montgomery	026,059,080							
Morgans		421						
MTC	080,212							
Multisystem	159							
Multitech	096,170,172	325,382						
Murphy(UK)	041							
NAD		363						
Nacnis	=> REX							
NEC	080,184	313,320,374	422,478,493	496		649		
Neckermann	004,026,044,055 082,097,170	369,356,373,374 379,386,387	421					
N.E.I.	166							
Network		394						
Nobilko	003,008,029,051 146	369,373						
Nogamatic(F)	=> Thomson							
NOKIA	=> ITT-NOKIA							
Normende	065,067,075,088 089,100,101,102 103,104,134,185 186,222	292,295,296,297 318,319,321,323 324,326,327,328 329,330,356,374 380			633,647			
OAK				500				
Obritech		426						
Oceanic(F)	005,040,105,106 107							
Onceas	004							
Onkyo				634,635	613 614 615 616			
Orion	006,016,028,057 088,108,109,187 188,189	322,331,332,333 360,387						
Osaki		383						
Otto Versand	025,027,044,052 055	379,386						
Pace			394,395,400 402,485					
Pael	003,008							
Palcom		396						
Palladium	197	356,372	421					
Palsat		423						
Panasonic /National	001,003,019,026 037,040,106,110 111,112,114,190 202,241	290,312,354,375 473		636		573,57461 9,660		
Pansat		455						
Paragon				531				
Pathe Marconi(F)	=> Thomson							
Penney	080	313						
Pentax		389						
Philco	019,023,024,025 026,080,151,155 169,170,231,477 229							
Philex		302,334,335,336 369,379	402,424,425 477,528			579 604 650 651	559	560(EQ) 561(PIP) 562(TAPE) 565(TUNE) 567(DCC)
Phoenix	=> Formenti - Phoenix							
Phonola	175	335,379						
Pioneer	000,027,067,243	320,334,336,363 364,365,379	474		643	555 610 652	571,640	
Polestar	214							
Prandoni-Prince	008,032,146							
Praxis	217							
Premier			527					
Primestat			454					
Prince	=> Prandoni - Prince							
Prosat	001	405,451,479						

Brand/Device	TV/TXT	VCR	SAT	CABLE	HIFI	CD	LD/VCD	AUX
Proton	080					651		
PYE		320						
PYE(UK)	=> Philips							
Quartz		314						
Quasar	=> Sambers							
Quelle	004,005,007,008 009,010,013,016 026,027,028,045 050,051,052,069 094,153,221,231 232,234,235,236	298,369,373,376 379,387	546					
Radiola(F)	=> Philips							
Radiomarelli	=> Magnadyne							
Radionette	=> Magnadyne							
Radio Shack	278					647		
Radiotone			409,428,430 487					
Radix								
Rank(UK)	=> RBM(UK)							
RBM(UK)	022,094							
RCA	080,204,210,211	349	450(DSS)			602		
RC-AK			456					
Redifusion(UK)	005,041,116							
REX	011,021,032,078 079,118	292,319,374						
Roadstar	039							
Robotron	=> Bruns					582 583 651	584(TAPE)	
ROTEL	=> Bruns							
SABA	000,065,067,075 085,098,099,100 103,117,155,185 186,222,224	292,295,319,319 321,326,337,338 356,374,380						
SAE						651		
Saisho	004,006,028,088 182,244	322,332,360,387 388						
Sakura			397,398					
Salora	005,047,048,055 066,068,069,076 082,086,097,162 177,195,249,250 265,286	314,384,386	418,554					
Sambers	000,004,008,029 030,043							
Samsung	026,033,043,080 159,160,170,175 212,215,269,270	289	459,475,476			664		
Sansui		320				603		
Sanyo	013,031,044,074 119,120,121,123 162,167,170,182 195,205	291,314,316,339			637	604 606		
SAT 100			488,535					
Sateco			426					
Schaub Lorenz	=> ITT-NOKIA							
Schneider	004,011,015,019 025,036,038,255 258,262	289,379,382						
Scientific Atlanta			452					
Scott	059							
Sears	059,205,275	315						
SEG	096	289,382						
Saleco	011,058,078	309						
Senta		378						
Sharp	044,054,119,124 196,198,225,227	301,302,341			629	566 648	661	
Sherwood						577,578 621,638		
Shinton		356						
Siaram	000,025,029,155 001							
Sicatel								
Siemens	010,231,232,233 234,236	291,369,373,376	546					
Siera	=> Philips							
Siesta	254							
Silver	160							
Singer	025,029,147,149 155							
Sintrack			427					
Sinudyne	006,016,025,026 029,057,109,125 155,192,197	379,388						
Skylight				512				
Skymaster								
Sony	028,044,119,126 127,128,129,130 182,199,228,260 282,288	298,299,340,342 343,344,367,390	472		617	556 557 575 607	575,656 563(TAPE) 575(CDV) 618(TUNE)	
Soundesign	080							
SSS	080,278							
Star		470						
Stern	=> REX							
Strong			399,423,426 480					
STS			393					
STV			413					
Sylvania	026					604 651		
TADA				448,523				
Tai Wah	218,219							
Tandberg	016,180,264	322						
Tantec			396					
Tatung	002,004,026,028 031,033,131	379						
Tay Shoen				506				
Teac						608 611		

Brand/Device	TV/TXT	VCR	SAT	CABLE	HIFI	CD	LD/VCD	AUX
TEC	=> Dual-Tec							
Technics					641	558 609		
Technisat			409,428,429 430,431,487 467					
Technosat								
Technovision	263							
Techwood	080							
Tedelex			466					
Teknika	059,080,092,212 278		471					
Tela e1			248					
Teleavia(F)	=> Thomson							
Telefunken	067,075,098,132 133,134,135,140 185,186,231,235	292,318,319,321 323,330,345,346 347,356,374,380						
Telemax			432					
Telemaster		359	398,409,428 430,469,487					
Teleservice	203,246							
Televideo	=> Formenti - Phoenix							
Telstra				496				
Tempest	160,175							
Thomson	065,067,075,078 098,100,103,185 186,222	292,318,323,324 328,356,374,380						
Thorn-Ferguson	001,135,136,137 140,144,148,152 160,186,229,256	308,303,304,305 306,308,319,329 330,348,356,368 374	394,395,400 401,402,433 485					
TMK	080		387					
Toshiba	022,044,094,119 138,139,141,142 205	292,307,374	442,444				571,620	
TPS			530					
Trans				497,518 520				
Trans Continens	=> Prandoni - Prince							
Uher	011,012,036,037 038,078,255	289,374						
Ultravox	003,025,082,096 146,155	377						
Uniden			403,404,406 443					
United Satellite			440					
Universum	094,160,221							
Univox	001							
US Electronics			417					
Vector		313	430,487					
Vagavox	169							
Victor		318,328,366					605	
Video		313						
Vidtech	080							
Viewstar			477					
Vortic Star			522					
Voxson	032,155							
Vtech			434					
Wards	026,059,080							
Watson	037							
Watt Radio	001,003,025,029 030,057							
Wega Color	119,143							
White Westinghouse	003,037,159	377,383						
Winer			449,550			501		
WISI			409,420,435 436,437,438 439					